Panasonic

Digital Copier

Operating Guide (For Copier)

FP-D250/D350/D350DC
FP-D350H/D450/D600

Options

FA-A355/A888/F320/F350/F355/FK35/TR350/TR355
FA-RU350/DS725/DS825/MA301/MADM65



Before operating this copier, please read these instructions completely and keep this operating guide for future reference.

The digital copier with options (See P.49)

English

Energy Star



The FP-D250/D350/D450/D600 series copiers comply with Tier 2 of the Environmental Protection Agency's Energy Star Program. This voluntary program specifies certain energy consumption and usage standards for copiers. These copiers will automatically "power down" after a specified period of non-use. The use of these Energy Star compliant copiers will reduce energy consumption and ultimately benefit the environment.

The default functions can be adjusted depending on your office requirements. Please see your authorised Panasonic copier dealer for more details.

Table of Contents

Before Operation

Operation Chart
- Common features and usage 4
- Function Categories 5

Precautions 6
- Control Panel 9
- Touch Panel Display 10

Making Copies

Basic Menu
- Full Size Copying 12
- Reduction or Enlargement Copying 13
- Using the Sheet Bypass 14

Duplex/Original ▶ Copy
- 1 ➡ 2/2 ➡ 1/2 ➡ 2 Copy 16
- Book ➡ 2 Copy 17
- 2 Page Copy 18
- N in 1 Copy 19
- 1 to N Copy 20
- SADF Mode 21

Zoom/Effects
- Zoom Copying 23
- Centring/Mirror/Inverse copy 24
- Edge/Margin/Book Mode 25
- Page numbering 26

Insertion Job
- Cover/Page Insertion 28
- OHP Interleaving/Presentation 29

Other Features
- Job Memory 30
- Sky Shot Modes 31
- Energy Saver/Interrupt 33
- Combining Function Table 34

User Preset 35
- General Functions 36
- Copier Settings 37
- General Functions for Key Operator 38
- Copier Settings for Key Operator 42

Options

- Options 49
- i-ADF/ADF 50
- 3 Bin Finisher, Exit Guide Unit 52
- 2 Bin Finisher, Exit Guide Unit 55
- Inverting Shift Tray 60

Maintenance

Handling
- Adding Paper 61
- Adding Toner 63
- Removing a Paper Misfeed 65

Checking
- Troubleshooting 76

Specifications 78

System Information 82

Operation Chart

Common features and usage

■ Basic Operation



■ Position of the original



- Place face down on platen and in ADF (FA-A355). Face Up in i-ADF (FA-A888).
- If the original is incorrectly placed on the platen glass, part of the copy image may be missing.
- For originals smaller than A5 size, align with centre of left original guide and select A5.

■ Memory capacity:

When the memory becomes full during the original scanning, the message of "Function not available for lack of memory" will be displayed in the message display.
In this case, follow the operating instruction in the message display.
When the additional memory is required, consult with authorised dealer.

NOTE

* While the copier is warming up, you may position your original on the copier, enter your copy job selections and press the Print key. The wait indicator will flash until the warm up cycle is completed and the copy job automatically start.

- When making 100 copies continuously or intermittently within 20 minutes, the fan motor will start rotation. This is not irregular operation but just to cool off the machine.

Operation Chart

Touch Panel Display

■ Function Categories

A



Basic Menu (See page 12)
① Text, Text/Photo, Photo Mode Key
② Exposure Control Keys
③ Auto Exposure Key
④ Cassette Indication
⑤ Cassette Selection Key
⑥ Job Status Key

B



Duplex/Original ▶ Copy (See page 15)
① 1 ➡ 2 Copy Key
② 2 ➡ 1 Copy Key
③ 2 ➡ 2 Copy key
④ Book ➡ 2 Copy Key
⑤ 2 Page Copy Key
⑥ N in 1 Copy Key
⑦ 1 to N Copy Key
⑧ SADF Key (See NOTE on page 15)

C



Zoom/Effects (See page 22)
① Zoom Key
② Centring Mode Key
③ Page Numbering Mode Key
④ Edge Mode Key
⑤ Margin Mode Key
⑥ Book Mode Key
⑦ Mirror Mode Key
⑧ Inverse Mode Key

D



Insertion Job (See page 27)
① Cover Mode Key
② Page Insertion Mode Key
③ OHP Interleaving Mode Key
④ Presentation Mode Key

E



Job Memory (See page 30)
① M1, M2, M3, M4, M5 Key
② Memory In Key



■ Basic Menu Selection
- Displays all functions when touching Basic Menu Key.
- Touch Basic Menu Key again to return to the basic screen.

Precautions

For your safety

■ Laser Safety

Caution
This product utilizes a laser.
Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

■ Caution Labels


DANGER Invisible laser radiation when open. Avoid direct exposure to beam.
CAUTION Invisible laser radiation when open. Avoid direct exposure to beam.
ATTENTION Rayonnement laser invisible si ouvert. Dangereux de regarder a l'interieur.
VORSICHT Unsichtbare laserstrahlen wenn geöffnet. Nicht hinensehen.
PRECAUTION Peligro-Cuando la cubierta esté abierta se podrá escapar radiación de rayo láser. Evite la exposición directa al rayo láser.
注意 危險！ 打開此蓋會有看不見的雷射放射線，請避免直接曝露於放射線下。
注意 危険-開けたときレーザー放射あり。ビームに直接さらされることを避けよ。
Laserstrahl
LASER KLASSE 1
LASER CLASSE 1
RANGO LASER 1
CLASS 1 LASER PRODUCT
(TO IEC 825)
FFPTE1538
CAUTION: Invisible laser radiation when open and interlocks defeated. AVOID EXPOSURE TO BEAM.
VORSICHT: Unsichtbare Laserstrahlung, wenn Abdeckung geöffnet und Sicherheitsverriegelung überbrückt. NICHT DEM STRAHL AUSSETZEN.
ATTENTION: Rayonnement laser invisible dangereux en cas d'ouverture et lorsque la sécurité est neutralisée. EXPOSITION DANGEREUSE AU FAISCEAU.
PELIGRO: Cuando se abre y se invalida el bloqueo, se producen radiaciones invisibles de láser. EVÍTESE LA EXPOSICIÓN DIRECTA A TALES RAYOS.
VARNING: OSYNLIG LASER-STRÅLNING NÄR DENNA DEL ÄR ÖPPNAD OCH SPÄRRAR ÄR URKOPPLADE. STRÅLEN ÄR FARLIG.
VAROI: NÄKYMÄTÖN AVATTAESSA JA SUOJALUKITUS OHITETTAESSA OLET ALTTIINA LASERSÄTEIL YLLE. ÄLÄ KATSO SÄTEESEN.
VARNING: OSYNLIG LASER-STRÅLNING NÄR DENNA DEL ÄR ÖPPNAD OCH SPÄRREN ÄR URKOPPLAD. BETRAKTA EJ STRALEN.
ADVARSEL: USYNLIG LASERSTRÅLING VED ÅBNING NÅR SIKKERHEDSAFBRYDERE ER UDE AF FUNKTION. UNDGÅ UDSÆTTELSE FOR STRÅLING.
ADVARSEL: USYNLIG LASERSTRÅLING NÅR DEKSEL ÅPNES OG SIKKERHEDSLÅS BRYTES. UNNGÅ EKSPONERING FOR STRÅLEN.
FFPTE2412

Handling



■ Do not look directly at exposure lamp when copying.



■ Do not turn the power switch off or open the front panel during copying.

● Do not drop paper clips or other metal objects into the copier.

Toner and Paper



■ Store toner, developer and paper in cool areas with low humidity.

● High quality paper of 60 – 90 g/m^2 (55 – 130 g/m^2 via sheet bypass) may be used.

● For optimum copy quality, it is essential that Panasonic Brand Toner is used in the copier.

Ventilation



■ The copier should be installed in a well-ventilated area to minimize the ozone density in the air.

Precautions

Installation





■ The copier should not be installed in areas with the following conditions:

- Extremely high or low temperature and humidity.
  Ambient Conditions Temperature: 10°C – 30°C
  Relative humidity: 30% – 80%
- Where temperature and humidity can change rapidly, causing condensation.
- Direct exposure to sunlight.
- Directly in air conditioning flow.
- In areas of high dust concentration.
- In areas of poor ventilation.
- In areas with chemical fume concentration.
- In areas with extreme vibration.
- Unstable or uneven floors.

FOR YOUR SAFETY

This appliance is supplied with a moulded three pin mains plug for your safety and convenience.
A 13 amp fuse is fitted in this plug.
Should the fuse need to be replaced please ensure that the replacement fuse has a rating of 13 amps and that it is approved by ASTA or BSI to BS1362
Check for the ASTA mark ⓐ or the BSI mark ⓚ on the body of the fuse.

If the plug contains a removable fuse cover you must ensure that it is refitted when the fuse is replaced.
If you lose the fuse cover the plug must not be used until a replacement cover is obtained.
A replacement fuse cover can be purchased from your local Panasonic Dealer.

IF THE FITTED MOULDED PLUG IS UNSUITABLE FOR THE SOCKET OUTLET IN YOUR OFFICE THEN THE FUSE SHOULD BE REMOVED AND THE PLUG CUT OFF AND DISPOSED OF SAFELY.
THERE IS A DANGER OF SEVERE ELECTRICAL SHOCK IF THE CUT OFF PLUG IS INSERTED INTO ANY 13 AMP SOCKET.
If a new plug is to be fitted please observe the wiring code as shown below.
If in any doubt please consult a qualified electrician.

WARNING: THIS APPLIANCE MUST BE EARTHED.

IMPORTANT: The wires in this mains lead are coloured in accordance with the following code:
Green and Yellow: Earth
Blue : Neutral
Brown : Live

As the colours of the wires in the main lead of this appliance may not correspond with the coloured markings identifying the terminals in your plug, proceed as follows:
The wire which is coloured GREEN-AND-YELLOW must be connected to the terminal in the plug which is marked by letter E or by the safety Earth symbol "⏚" or coloured GREEN or GREEN-AND-YELLOW.
The wire which is coloured BLUE must be connected to the terminal in the plug which is marked with the letter N or coloured BLACK.
The wire which is coloured BROWN must be connected to the terminal in the plug which is marked with the letter L or coloured RED.

How to replace the fuse.
Open the fuse compartment with a screwdriver and replace the fuse.



Caution Note: Disconnect from the mains supply before removing covers.

The mains plug on this equipment must be used to disconnect mains power. Please ensure that the socket outlet is installed near the equipment and shall be easily accessible.

Control Panel



No	Contents	Refer to
①	**Multi-Size Feed Key** ● When Multi-sized originals are copied using i-ADF/ADF (Option).	P.51
②	**Sort/Finish Key** ● When sorting and stapling with Finisher (Option).	P.52 – 60
③	**User Preset Key** ● Changes default modes.	P.35 – 48
④	**Energy Saver Key** ● Can save power while the copier is not in use.	P.33
⑤	**Manual Key** ● After pressing this key, the original size can be selected manually.	P.12
⑥	**Interrupt Key** ● Interrupts other copy or print jobs while making copies.	P.33
⑦	**Reset Key** ● Resets all features to the initial power-on state.	———
⑧	**Clear Key** ● Clears the copy count in the display.	———
⑨	**Stop Key** ● Stops the copy run.	———
⑩	**Operation Switch** (FP-D450/D600 only) ● For turning the power On/Off.	———

NOTE

● Above control panel is only for copier functions. Please refer to the proper operation guide for the Printing and Filing control panel functions.

Control Panel

Touch Panel Display



- **Adjusting the touch panel display contrast**
  Adjust brightness of the display by repeatedly pressing A3 or A5 original size key while pressing and holding the Clear key.
  To make the display brighter: A3 size key
  To make the display darker : A5 size key

ATTENTION

- Use soft finger pressure only to activate touch Screen panel. DO NOT USE SHARP OBJECTS such as pens, fingernails etc., as this may damage the panel.

■ Touch Panel Display Indications

No	Contents	Refer to
①	Warning indications : Add Toner : Add Paper : Replace waste toner bottle. : Call service	P.61 – 64
②	SADF/Multi-size Feed Mode indication	P.21, 51
③	Original Image indication	———
④	Rotate Mode indication*	P.60
⑤	Copy paper indication	———
⑥	Number of copies	———
⑦	Machine/User Error Code indication (E1-01, U13, etc.,)	P.75
⑧	Function Categories	P.15 – 32
⑨	Copy Paper Size indication	———
⑩	Finisher Functions indication	P.52, 60
⑪	Selected Paper Tray and Paper status indication 2: Tray position : Normal : Low paper : Add Paper	———
⑫	Cassette Selection Key	P.13
⑬	Manual Exposure Select keys (Light and Dark)	P.12
⑭	Original Mode Select key (Text/Text/Photo/Photo)	P.12
⑮	Job Status Key	P.12
⑯	Auto Exposure Key	———
⑰	Exposure Indicator (7 steps)	———
⑱	Copy Ratio indication	———
⑲	Original Size indication	———

NOTE

* When making copies in A4 (▯) if the cassette runs out paper, the copier will automatically select the A4R (▭) cassette and rotate the image to said. However, the function is not available if any problem occures by the image rotation function in the middle of copy operation. (Duplex/Original → copy, Insertion job, Sort/Finish mode, etc.)

Full Size Copying

When copying the same size as the original (1:1)

■ Copy size and copy density are automatically selected.



1 **Original Size Keys**

Touch Panel Display

2

3

Position original

Number of copies
Up to 999

Press **Print**

■ Initial Screen

(When placing A4 size originals)



Input the code number, if U0 appears.

①Select the original(s)

- Text: Originals are mainly composed of text.
- Photo: Originals are mainly composed of photo.
- Text/Photo: Combined originals with text and photo.

②**Job Status Key**

- Each setting jobs will be indicated on the display. See page 15 – 30 for job settings.

■ When manually selecting exposure control or original size:



Select exposure control

- Press the Light or Dark key.

The centre setting is the normal (auto) position.



Select original size.

①Press Manual key.

Lights up (Manual mode)



②Select original size with Original Size key.

NOTE

- **Benefits of QUARC (QUAlitative Reasoning based adaptive Controller).**
The FP-D250/D350/D450/D600 series features exclusive new Panasonic imaging technology which utilises an advanced form of artificial intelligence to ensure optimal copy quality and performance under varying environmental conditions, from a wide range of originals.

Reduction or Enlargement

When copying with preset ratios

■ **There are 5 preset reduction and 5 preset enlargement modes.**



1 Position original

2 Select the copy size
(Landscape for A4/A5 size)

3 Number of copies

4 Press **Print**





Paper Tray (CASSETTE) Key

Example: Reduction

Original size → Copy size

A3 → A4

The correct ratio is automatically selected.

Reduction and enlargement ratios. (%)

Original size	Copy size			
	A3	B4	A4	A5
A3	100	87	71	50
B4	115	100	82	58
A4	141	122	100	71
A5	200	173	141	100

● When changing the paper size, touch **Cassette** key.

ATTENTION

● Part of the image may be deleted if the direction of the original and copy paper do not correspond.

NOTE

● If the copy size is different from the paper size you can use the sheet bypass. This will save you having to change the setting of the paper trays.

Using the Sheet Bypass

When copying on special paper, etc.

■ **To copy on letterhead, mailing labels, transparencies and odd-size paper, etc., or to use the bypass as an additional paper source.**

1

Position original.

2



Open the Sheet Bypass.

3



Pull out the Sheet Bypass tray until it stops.

4



①Place approximately 50 sheets of paper.

Insert the paper until it stops.
②Adjust the side guides.
Incorrect adjustment may cause paper to wrinkle, misfeed or skew.

5

Press **Print**.

NOTE

- The bypass has priority over the paper trays. The copier automatically selects the Sheet Bypass when paper is placed in the empty bypass tray.
- Some types of mailing labels and transparency film may damage your machine. Please contact your service provider for advice regarding non-standard paper types.
- Do not feed curled paper through the bypass to avoid misfeed.

Duplex/Original ▶ Copy

When touching DUPLEX/ORIG. ▶ COPY key

■ Initial Screen



● Touch the desired key to select the function.

1 ➡ 2	From single sided originals to double sided copies.	⇒ See P.16
2 ➡ 1	From double sided originals to single sided copies.	⇒ See P.16
2 ➡ 2	From double sided originals to double sided copies.	⇒ See P.16
Book ➡ 2	From book originals to double sided copies	⇒ See P.17
2 Page	Copying two facing pages of an A3 size original on two separate A4 size sheets.	⇒ See P.18
N in 1	From two (or four) single sided originals onto side by side single sided copies.	⇒ See P.19
1 to N	From one 1-sided original to two (or four) 1-sided copies.	⇒ See P.20
SADF	A special original (like thin paper etc.,) can be fed from the ADF/i-ADF original tray.	⇒ See P.21

NOTE

* Displays when selecting "Yes" with the SADF function. (See P.42)

● To copy double sided originals you can use the i-ADF (FA-A888) or place double sided originals directly onto the original glass.

● ADU (Automatic Document Feeder) is required when making a 2-sided copy.

● To reset Duplex/Original ▶ Copy mode, press Reset key.

Duplex/Original ▶ Copy

1 ➡ 2/2 ➡ 1/2 ➡ 2

■ **1 ➡ 2 Copy**
From single sided originals to double sided copies.
From Copier Platen & ADF/i-ADF



■ **2 ➡ 1 Copy**
From double sided originals to single sided copies.
Using i-ADF



■ **2 ➡ 2 Copy**
From double sided originals to double sided copies.
Using i-ADF



■ **Procedure**





2 Place originals

3 Count originals (1 ➡ 2 only)

(4) Select original size

1 Touch 1 ➡ 2, 2 ➡ 1 or 2 ➡ 2

5 Number of copies (Up to 50)

6 Press **Print**



① For odd or even originals, touch the Odd or Even key.

② If number of originals is unknown, touch Original Count key.

③ Touch **OK** key.

④ Return Originals to the ADF/i-ADF.

NOTE

- To reset a mode selected using the menu, touch Cancel key on the touch panel.
- Press the reset key to feed out last copy existing in the ADU (Automatic Duplex Unit).

Book ➡ 2

■ **Book ➡ 2 Copy**
From book originals to double sided copies
A3 size originals only.



(Book Format)



(Facing Pages)



1 Position original on the Platen

2 Select the copy size

3 Select Book ➡ 2 mode and Copy format

4 Number of copies (Up to 50)

5 Press **Print**



● Copy last page first in Facing pages and Book Format mode.



● Touch **OK** key.

NOTE

- To reset a mode selected using the menu, touch Cancel key on the touch panel.
- Press the reset key to feed out last copy existing in the ADU (Automatic Duplex Unit).

2 Page Copy

■ **2-Page Copy**
Copying two facing pages of an A3 size original on two separate A4 size sheets.



A3 size originals only.

■ Procedure



2 Place originals

(3) Select copy size*

1 Touch 2 Page mode

4 Number of copies

5 Press **Print**

Book on the platen

A3 size original



Centre

Centre book by length and width according to centre marks.

Centre (Book) mark

NOTE

* For reduction or enlargement copy only.

● To reset a mode selected using the menu, touch Cancel key on the touch panel.

N in 1

■ 2 in 1 Copy

From two (or four) single sided originals onto side by side single sided copies.



■ 4 in 1 Copy

From four 1-sided originals, side by side, to 1-sided copies.



■ Booklet

From four 1-sided originals, side by side, to 2-sided copies.



■ Procedure





Copy size*

2 Place originals

3 Count originals (except Booklet)

1 Touch N in 1 mode and make selection

4 Number of copies

5 Press **Print**





①Touch **ADF** key.
②After originals are counted, touch the **OK** key.
③Re-position originals in document feeder.

NOTE

* Copy is automatically reduced.
(ex. A4 to A4 size)
2 in 1: 71%, 4 in 1: 50%

- A4 ▯ size originals only for Booklet.
- The ADF/i-ADF is required for N in 1 copy.

Duplex/Original ▶ Copy

1 to N

■ 1 to 2 Copy

From one 1-sided original to two 1-sided copies.



■ 1 to 4 Copy

From one 1-sided original to four 1-sided copies.



■ Procedure





Copy size*

2 Place originals

1 Touch N in 1 mode and make selection

3 Number of copies

4 Press **Print**



NOTE

- To reset a mode selected using the menu, touch Cancel key on the touch panel.

* Copy is automatically enlarged.
(ex. A4 to A4 size)
1 to 2: 141%, 1 to 4: 200%

SADF MODE

■ SADF (Single Automatic Document Feeder) Function

A special original (like thin paper etc.,) can be fed from the ADF/i-ADF original tray and copied continuously with manual operation.

Select SADF setting "Yes" in the user preset mode before using this function. (See page 42)

■ Procedure



NOTE

- SADF function cannot be combined with 2 ➜ 1, 2 ➜ 2, N in 1 and Finishing function (except Non-sort).
- Set the original from the last page in 1 ➜ 2 copy mode.
- To reset a mode selected using the menu, touch Cancel key on the touch panel.

Zoom/Effects

When touching ZOOM/EFFECTS key

■ Initial Screen



● Touch the desired key to select the function.

Zoom	Copies with variable zoom ratios from 25% to 400% in 1% increments.	⇒ See P.23
Centring	Shifts image to centre.	⇒ See P.24
Page Numbering	Prints a page number on the copies.	⇒ See P.26
Edge	Creates a blank edge.	⇒ See P.25
Margin	Shifts image to right or left.	⇒ See P.25
Book	Eliminates dark inner binding shadows.	⇒ See P.25
Mirror	Copies a mirror image.	⇒ See P.24
Inverse	Copies a inverse image. ● Negative to Positive ● Positive to Negative	⇒ See P.24

NOTE

- To reset Zoom/Effects mode, press Reset key.
- For combining Zoom/Edit functions and other functions, see page 34.
- Press the Clear key and re-enter the correct number if you make a mistake.

Zoom Copying

■ Zoom

Copies with variable zoom ratios from 25% to 400% in 1% increments.

■ Auto Zoom

Copy ratio can be selected automatically by selecting the paper size.



1 Position original (On the platen when Auto Zoom)

2 Select Zoom/ Effect mode

3 Select Zoom or Auto Zoom

4 Select paper

5 Number of copies

6 Press **Print**. (In Auto Zoom mode, make copies with ADF/i-ADF or platen cover open.)

3 Select Zoom or Auto Zoom and touch OK.



Zoom

Select zoom ratio by using ▲·▼ keys and touch OK.



X·Y key

When setting X, Y zoom ratio individually, press X, Y key first, then set the zoom ratio by using ▲·▼ key.

Auto Zoom

Select mode and touch OK.



Setting X, Y zoom to same ratio along with the height or width (whichever shorter) of the copy paper.



Setting X, Y zoom ratio individually along with the height and width of the copy paper.

4 Select paper size and touch OK.



ATTENTION

- When changing paper size after setting zoom ratio, please use cassette key. If you use copy size key, zoom ratio will be changed.

NOTE

- Remove the originals from the ADF/i-ADF before selecting the auto zoom mode.
- Incorrect original position detection may occur if any strong light shines onto the platen glass during the auto zoom mode.
- To reset a mode selected using the menu, touch Cancel key on the touch panel.

Zoom/Effects

Centring/Mirror/Inverse

■ Centring

Copy image can be centred automatically on selected paper.



■ Mirror

A mirror image can automatically be made.



■ Inverse

Negative/Positive image can be made for interesting effects.



■ Procedure



NOTE

* In centring mode, make copies with ADF/i-ADF or platen cover open. Remove the originals from the ADF/i-ADF before selecting the centring mode.

- Incorrect original position detection may occur if any strong light shines onto the platen glass during the centring mode.
- To reset a mode selected using the menu, touch Cancel key on the touch panel.

Edge/Margin/Book

■ Procedure



1 Position original
2 Select Zoom/ Effect mode
3 Select Edge Margin or Book
(4) Select paper
5 Number of copies
6 Press **Print**

Edge



① Select vertical or horizontal edge.
② Adjust each void width by using the ▲·▼ keys.
③ Touch **OK** key.
④ When the void areas are both the same for vertical and horizontal, adjust the void width by using the ▲·▼ keys, then touch **OK** key.

* Initial setting (Factory setting): 5 mm

Margin



① Select margin area
② Adjust each void width by using the ▲·▼ keys.
③ Touch **OK** key.

* Initial setting (Factory setting): 10 mm

Book



① Adjust each void width by using the ▲·▼ keys.
② Touch **OK** key.

* Initial setting (Factory setting): 20 mm

NOTE

* Initial setting (Factory setting) can be changed by the User Mode function. (Please refer to page 37)

● To reset a mode selected using the menu, touch Cancel key on the touch panel.

Zoom/Effects

Page Numbering

■ Feature

The page number can be automatically printed on each page.



1 Position original (ADF/i-ADF)

2 Select Zoom/ Effect mode

3 Select Page Numbering

4 Select paper

5 Number of copies

6 Press **Print**





① Select print position for page numbering.

② Select the first page to begin page numbering using 10-key on the control panel. Page 1, 2 or 3 can be selected.

③ Touch **OK** key.

④ Touch **ADF** key.

⑤ Touch **OK** key.

⑥ Position original again.

- Page number is indicated with -n- or n/m form. (Example)

NOTE

- The ADF/i-ADF is required for Numbering.
- The page numbering format can be changed in user preset mode. (See P.36)
- To reset a mode selected using the menu, touch Cancel key on the touch panel.

Insertion Job

When touching INSERTION JOB key

■ Initial Screen



● Touch the desired key to select the function.

Cover	Adds cover page(s) to the copies.	⇒ See P.28
Page insertion	Inserts paper between the copies.	⇒ See P.28
OHP interleaving	Inserts paper between OHP film.	⇒ See P.29
Presentation	Inserts paper between OHP film and makes copied sets for hand-outs.	⇒ See P.29

NOTE

● The i-ADF/ADF is required for Insertion Job.

● To reset Insertion job, press reset key.

Insertion Job

Cover/Page insertion

■ Cover

Adds cover page(s) to the copies.

Blank Paper



Copied Paper



■ Page insertion

Inserts paper between the copies.

Blank Paper **Copied Paper**



■ Procedure

ADF **i-ADF**





1 Position original (Up to 50)

2 Select Cover or Page Insertion

3 Select cassette

4 Number of copies

5 Press **Print**

Cover

2 ① Select Cover mode (Front or Front/Back)
② Select Blank or Copy
③ Touch **OK** key.



3 ① Touch **ADF** key (Count originals)
② Select cassette and touch OK key.



Page insertion

2 ① Select Blank/Copy mode
② Touch **OK** key.



3 ① Touch **ADF** key (Count originals)
② Select cassette and touch OK key.
③ Input insert position (Up to 20)
④ Touch **OK** key.





NOTE

- The number of the originals can be input using the ten key instead of the ADF originals count.
- To reset a mode selected using the menu, touch Cancel key on the touch panel.

OHP interleaving/Presentation

■ OHP interleaving

Inserts paper between OHP film.

Blank Paper



Copied Paper



■ Presentation

Inserts paper between OHP film and makes copied sets for hand-outs.

Blank Paper + Copies



Copied Paper + Copies



■ Procedure



1 Place OHP (Sheet Bypass)

2 Place originals

3 Select Insertion Job mode

4 Select blank/copy paper

5 Select cassette

6 Number of copies

7 Press **Print**

4 **OHP interleaving**
Select blank/copy and touch OK key



Presentation
Select blank/copy insertion and touch OK key



5 **OHP interleaving**
Select cassette



Presentation
Select cassette



NOTE

- To reset a mode selected using the menu, touch Cancel key on the touch panel.

Job Memory

■ **Five copy jobs can be programmed in memory (M1 to M5) for recall at a later time.**




Job memory
Select Mem. in or Mem. #
X = more setting
❸ M in
❷ JOB MEMORY
BASIC MENU
DUPLEX / ORIG.▸COPY
ZOOM / EFFECTS
INSERTION JOB
SIZE 1 70㎜ X160㎜ M 1
SIZE 2 95㎜ X220㎜ M 2
B4 100 % B4 M 3
A4 X= 90% Y= 95% A4 M 4
A3 50 % A5 M 5
❹

To store a job into a memory

① Set up the copy job to be stored in memory.
② Press Job Memory key
③ Touch **Memory In** key. (M IN)
④ Touch **M1**, **M2**, **M3**, **M4** or **M5** key.



To recall a job from memory mode.

⑤ Press Job Memory key
⑥ Touch **M1**, **M2**, **M3**, **M4** or **M5** key.
⑦ Press **Print**

☒: Means there are more settings other than what is indicated on the display.

NOTE

- Job memory mode will not be deleted even if the Power Switch is turned off.
- When storing a new job, the previously stored job will automatically be deleted and the current job stored in its place.
- To reset Programming job, press reset key.

Skyshot Mode

Manual Skyshot Mode/Digital Skyshot Mode

■ To copy from the platen with the platen cover or ADF/i-ADF open. Two types of skyshot modes can be selected.

Manual Skyshot Mode: Making copies from small originals without dark areas around the image.

Digital Skyshot Mode: Copies can be automatically adjusted although they are not placed in parallel to the original guide. (except A3 and A4 ▯)

■ Setting the skyshot mode

1·3 Press User Preset

2 Set the Skyshot Mode





(1) Touch the COPIER SETTINGS key.

(2) Touch the ▶ key to open the 2/2 of Copier settings menu.

(3) Touch the Digital skyshot mode or Manual skyshot setting key.

(4) Select the desired function and touch OK key.
Digital Skyshot Mode
None
Free shape: Copy is made with slant.
Parallel: Copy is made to parallel. (within 5 degrees)
Manual Skyshot Mode:
OFF, M1 ON, M2 ON, M1&M2 ON

NOTE

- When changing the M1 or M2 size, please consult the key operator.
- Incorrect erasure may occur if there is a black line at the edge of the original or an image which the copier is detected as a black pattern in the skyshot mode.
- Incorrect original position detection may occur if any strong light shines onto the platen glass during skyshot mode.

Skyshot Mode

■ Operation

For Manual Skyshot Mode:





1 Position original

2 Select M1 or M2

3 Number of copies

4 Press **Print***

Example M1: i-ADF
M2: Platen

Touch Job Memory key.



Touch M1 or M2 key.



For Digital Skyshot Mode:







1 Position original on the Platen
(Make copies with ADF/i-ADF or platen cover open.)

2 3 Number of copies / Press **Print**

NOTE

* In the manual skyshot mode, A4 size paper is selected automatically.
- When using the manual skyshot mode (M1 and M2 are turned ON), the other job memory cannot be used.
- To reset the manual skyshot mode, press Reset key.
- To reset the digital skyshot mode, close the ADF/i-ADF or platen.

Energy Saver/Interrupt



■ This mode can save power while the copier is not in use.



Energy Saver Mode

①To enter this mode
Press Energy Saver key, the indicator will flash.
②To cancel this mode and make copies
Press Energy Saver key again.

Auto Off Mode

①Automatically enters after 60 minutes from the last copy. Copier power will drop and the indicator will light.
②To make copies, press Energy Saver key.

INTERRUPT



Interrupt Mode

● This mode can interrupt other copy jobs while making copies.

①Press **Interrupt** key, then indicator will light.
When pressing Interrupt key twice, interrupt mode is cancelled.
②Make other copy job.
Copies are exited to the interrupt tray when using 3-bin finisher (option), except for the staple sort mode using 3rd bin.
(See P.53)
③Touch **Interrupt** key again to continue original job.

NOTE

● Energy saver time (15 minutes) and Auto off time (60 minutes) can be changed by key operator. (See P.38)

Modes	Power Consumption		Warm Up Time	
	FP-D250/D350	FP-D450/D600	FP-D250/D350	FP-D450/D600
Normal Operation	Approx. 200 Wh	Approx. 230 Wh	None	None
Power Saving Mode	Approx. 135 Wh	Approx. 190 Wh	30 sec.	30 sec.
Auto Off Mode	Approx. 15 Wh	Approx. 15 Wh	75 sec.	180 sec.

Combining Function Table

First Selections \ Later Selections		DUPLEX/ORIG. ▶ COPY									ZOOM/EFFECTS									INSERTION JOB				Other Functions								
		1 ➡ 2	2 ➡ 1	2 ➡ 2	Book ➡ 2	2 Page	N in 1	Booklet	1 to N	Zoom	Auto Zoom	Centring	Page Numbering	Edge	Margin	Book	Mirror	Inverse	Presentation	OHP interleaving	Page insertion	Cover	Interrupt	Nonsort	Sort	Group	Staple sort	Punch	Manual skyshot	Digital skyshot
DUPLEX/ORIG. ▲ COPY	1 ➡ 2		–	–	–	–	○	–	–	○	○	○	○	○	○	○	–	–	–	–	○	○	○	○	○	○	○	○	–	○
	2 ➡ 1	–		–	–	–	–	–	–	○	–	–	○	○	○	–	–	–	–	–	○	○	○	○	○	○	○	○	–	–
	2 ➡ 2	–	–		–	–	–	–	–	○	–	–	○	○	○	–	–	–	–	–	○	○	○	○	○	○	○	○	–	–
	Book ➡ 2	–	–	–		–	–	–	–	–	–	–	–	○	○	○	–	–	–	–	–	–	○	○	○	△	–	–	–
	2 Page	–	–	–	–		–	–	–	–	–	–	–	○	–	○	–	–	–	–	–	–	○	○	○	△	–	–	–
	N in 1	○	–	–	–	–		–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	○	○	○	○	○	–	–
	Booklet	–	–	–	–	–	–		–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	○	○	○	△	–	–	–
	1 to N	–	–	–	–	–	–	–		–	–	–	–	–	–	–	–	–	–	–	–	–	–	○	○	○	△	–	–	–
ZOOM/EFFECTS	Zoom	○	○	○	–	–	–	–	–		–	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	–	○
	Auto Zoom	○	–	–	–	–	–	–	–	–		○	–	○	○	○	–	–	–	–	–	–	○	○	○	○	○	○	–	–
	Centring	○	–	–	–	–	–	–	–	○	○		–	○	○	○	○	○	–	–	–	–	○	–	–	–	○	○	–	–
	Page Numbering	○	○	○	–	–	–	–	–	○	–	–		○	○	–	–	–	–	–	○	○	–	○	○	–	○	○	–	–
	Edge	○	○	○	○	○	–	–	–	○	○	○	○		○	○	–	–	○	○	○	○	○	○	○	○	○	○	–	○
	Margin	○	○	○	○	○	–	–	–	○	○	○	○	○		○	–	–	–	–	○	○	○	○	○	○	○	○	–	○
	Book	○	–	–	○	○	–	–	–	○	○	○	–	○	○		–	–	–	–	–	–	○	○	○	○	○	○	–	○
	Mirror	–	–	–	–	–	–	–	–	○	–	○	–	–	–	–		○	–	–	–	–	○	○	–	–	–	○	–	○
	Inverse	–	–	–	–	–	–	–	–	○	–	○	–	–	–	–	○		–	–	–	–	○	○	–	–	–	○	–	○
INSERTION JOB	Presentation	–	–	–	–	–	–	–	–	○	–	–	–	○	–	–	–	–		–	–	–	–	–	○	–	○	○	–	–
	OHP interleaving	–	–	–	–	–	–	–	–	○	–	–	–	○	–	–	–	–	–		○	–	–	○	–	–	–	–	–	–
	Page insertion	○	○	○	–	–	–	–	–	○	–	–	○	○	○	–	–	–	–	–		○	–	–	○	–	○	○	–	–
	Cover	○	○	○	–	–	–	–	–	○	–	–	○	○	○	–	–	–	–	–	○		–	–	○	–	○	○	–	–
Other Functions	Interrupt	–	–	–	–	–	–	–	–	○	–	–	–	○	○	○	○	○	–	–	–	–		○	–	–	–	–	–	–
	Nonsort	○	○	○	○	○	○	–	○	○	○	○	○	○	○	○	○	○	–	○	–	–	○		–	–	–	○	–	○
	Sort	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	–	–	○	–	○	○	○	–		–	–	○	–	–
	Group	○	○	○	○	○	○	–	○	○	○	○	–	○	○	○	–	–	–	–	–	–	○	–	–		–	○	–	–
	Staple sort	○	○	○	△	△	○	–	△	○	○	○	○	○	○	○	–	–	–	–	○	○	–	–	–	–		○	–	–
	Punch	○	○	○	–	–	○	–	–	○	○	○	○	○	○	○	○	○	○	–	○	○	–	○	○	○	○		–	○
	Manual skyshot	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–	–		–
	Digital skyshot	○	–	–	–	–	–	–	–	○	–	–	–	○	○	○	○	○	–	–	–	–	–	○	–	–	–	○	–	

○: Combination use is possible. However it may not accepted when further multiple combinations are selected.
△: Combination use is not accepted on the FA-F320.
–: Combination use is not accepted, or not recommended.

User Preset

■ User Preset modes allow you to change the initial copy mode, if necessary.



■ Procedure





- Above screen is an example of multi functions model, FP-D350H.
- Menu locations may be different from above depending on the installed options onto the digital copier.

① Press User Preset Key.
- Setting menu will appear on the display.

② Select one of four functions.
- File and Printer settings are optional. (Except for the FP-D350H)

③ Select mode
- Input ID code for key operator settings.

④ Follow the on screen instructions.

⑤ After setting, touch OK key in Display Panel.

⑥ Press User Preset key or Reset key, then exit User preset mode.

NOTE

- Please refer to each operation guide for file settings and printer settings.

User Preset

General Functions

■ **User Preset modes allow you to change the initial copy mode, if necessary.** (See P.44 – 46)


User preset mode; general select item
OK
00 Finisher mode default Nonsort
01 Staple position Front
02 Power on default mode Copy
03 Manual add toner OFF
04 User information change
1/2



Screen No.	Modes	Function	Initial setting
1/2	00 Finisher mode default	Selects finisher mode. ● Non-sort, Sort, Sort/Staple, Group	Non-sort
	01 Staple position setting	Selects staple position. ● Front, Rear, Booklet	Front
	02 Power on default mode	* Selects mode. ● Copy or Filing	Copy
	03 Manual add toner	Allows the addition of toner as determined by operator. Toner is rapidly added after selecting ON and touching OK. ● OFF, ON	OFF
	04 User information change	* Allows changing user information as determined by operator. After user ID is entered or card is inserted, the following items can be changed. ● User name, Department name, Tel No., Code No.	
2/2	05 Hard disk status	* Hard disk condition will indicate on the screen for 3 seconds.	
	06 Departmental counter	Copy usage and copy limit of selected department and total copy usage will appear on the screen for 3 seconds.	
	07 Page numbering style	Selects numbering style ● -n- or n/m (ex: -1- or 1/10)	-n-
	08 Hole punch default	Selects hole punch mode ● OFF, ON	OFF
	09 Set key operator code	Input key operator ID code.	

NOTE

* Not needed in copying mode, but needed when installing options for advanced functions (see page 82) or using multi functions model (FP-D350H).

Copier Settings

■ User Preset modes allow you to change the initial copy mode, if necessary. (See P.44 – 46)


User preset mode; copier select item
OK
00 Margin value default 10mm
01 Edge value default 5mm
02 Book value default 20mm
03 Margin reduction def. 100%
04 Duplex mode default No
1/2


User preset mode; copier select item
OK
05 Reduce N in 1 for space No
06 Digital skyshot setting Freeshp
07 Manual skyshot setting OFF
08 Paper size priority A4
09 Set key operator code
2/2

Screen No.	Modes	Function	Initial setting
1/2	00 Margin value default	Selects the margin shift value. ● 5mm, 10mm, 15mm or 20mm	10mm
	01 Edge value default	Selects the edge width. ● 5mm, 10mm, 15mm or 20mm	5mm
	02 Book value default	Selects the book void width. ● 15mm, 20mm, 25mm or 30mm	20mm
	03 Margin reduction default	Selects the reduction ratio in margin mode. ● 100%, 95%, 93% or 91%	100%
	04 Duplex mode default	Determines most frequent usage mode ● No, 1 to 2, 2 to 2 or Book to 2	No
2/2	05 Reduce N in 1 for space	Selects whether or not to disable edge deletion ● No, Yes	No
	06 Digital skyshot setting	Selects whether or not to disable edge deletion* ● None, Free shape, Parallel	Free shape
	07 Manual skyshot setting	Enables or disables the use of Manual Skyshot. ● OFF, M1 ON, M2 ON, M1&M2 ON	OFF
-	08 Paper size priority	Specifies the paper size in manual paper size setting mode. ● A4, A4-R, B4-FLS, A3, A5	A4
	09 Set key operator code	Input key operator ID code.	

NOTE

* To copy from the platen with the original cover or i-ADF open. Normally, this makes a copy with a solid (black) area around the original if the original is smaller than the copy paper. This mode eliminates the solid area automatically.



Digital Skyshot Mode (OFF)



Digital Skyshot Mode (ON)

User Preset

General Functions for Key Operator

■ Input key operator ID code to change settings.


User preset mode; general select item
OK
00 Paper size
01 Auto reset time 1 min.
02 Energy saver time 15 min.
03 Auto off time 60 min.
04 Language default English
1/8


User preset mode; general select item
OK
05 Special paper tray 1 None
06 Special paper tray 2 None
07 Finisher bin function C/F/P
08 Auto paper out rotate OFF
09
2/8

Screen No.	Modes	Function	Initial setting
1/8	00 Paper size	Sets the paper size of each paper drawer. ● A3, B4, A4, A4-R, B5, B5-R, A5, FLS1, FLS2, Ledger, Legal, Letter, Letter-R, Invoice	Contact your service provider.
	01 Auto reset time	Selects the reset time. ● None, 45 seconds, 1 minute, 2 minutes	1 minute
	02 Energy saver time	Selects the energy saver time. ● 5/15/30/60 minutes, 1.5/2/3/4 hours	15 minutes
	03 Auto off time	Selects the Auto off time. ● No, 15/30/60 minutes, 1.5/3/4 hours	60 minutes
	04 Language default	Selects the message language of the display. ● Japanese, English or ● English, Swedish, Spanish	English
2/8	05 Special paper tray 1	Sets the paper drawer for special paper (eg: coloured). ● None, Copier upper, Copier lower, System Console Upper, Middle Lower, LCC, Bypass	None
	06 Special paper tray 2	Sets another paper drawer for special paper. ● Same as above	None
	07 Finisher bin function C: Copier P: Printer F: Filing	* Selects stack position for 3 bin finisher (Upper/Middle/Lower) ● C/F/P F/P/C C/P/F P/C/F F/C/P P/F/C	C/F/P
	08 Auto paper out rotate	Copier will automatically rotate image and print when selected paper drawer is empty. ● OFF, ON	OFF
	09 (Reserved)		

NOTE

* Not needed in copying mode, but needed when installing options for advanced functions (see page 82) or using multi functions model (FP-D350H).

● It is necessary to input operator ID code before changing items on this page.

General Functions for Key Operator

■ Input key operator ID code to change settings.





Screen No.	Modes	Function	Initial setting
3/8	10 Original set beep sound	—	—
	11 Original set beep sound in ADF	—	—
	12 Unknown access rights	* Selects the unknown access rights ● Group, Public	Group
	13 (Reserved)		
	14 Departmental counter mode	Monitors copy usage of each department (1) Copy usage of each department (2) Copy limit of each department (3) Copy number of each department	Contact your service provider.
4/8	15 No ID operation	* Operation for user without access rights ● No copy (prohibit all functions) No save (prohibit filing functions) Free (permit filing functions)	No save
	16 User registration	* Registers user to the copier ● User name, department, Tel No., user ID number, password	
	17 User delete	* Deletes user registration	
	18 User information change	* Changes user information registered	
	19 ID card change	* Changes ID card information registered	

NOTE

* Not needed in copying mode, but needed when installing options for advanced functions (see page 82) or using multi functions model (FP-D350H).

● It is necessary to input operator ID code before changing items on this page.

User Preset

General Functions for Key Operator

■ Input key operator ID code to change settings.



Screen No.	Modes	Function	Initial setting
5/8	20 Date time setting	Sets date time registered ● Day, Month, Year, Time	
	21 (Reserved)		
	22 TCP/IP address	✻ Sets user IP address ● 3 digit × 4	
	23 TCP/IP subnet mask	✻ Sets the subnet mask ● 3 digit × 4	
	24 TCP/IP default gateway	✻ Sets the gateway address ● 3 digit × 4	
6/8	25 (Reserved)		
	26 (Reserved)		
	27 (Reserved)		
	28 (Reserved)		
	29 DD file server IP add.	✻ Sets DD file server IP address ● 3 digit × 4	

NOTE

✻ Not needed in copying mode, but needed when installing options for advanced functions (see page 82) or using multi functions model (FP-D350H).

● DD file server: It is a Network server which is able to connect with the Hyper Document System (HDS). DD server software is required when the HDS server function is used.

● It is necessary to input key operator ID code before changing items on this page.

General Functions for Key Operator

■ Input key operator ID code to change settings.


User preset mode; general select item
OK
30 Hard disk backup select Manual
31 Hard disk backup time
32 Hard disk backup day Sunday
33 Backup to RMV media Stop
34 Restore from RMV media Stop
7/8



Screen No.	Modes	Function	Initial setting
7/8	30 Hard disk backup select	* Selects the Hard disk backup method ● Auto, Manual	Manual
	31 Hard disk backup time	* Sets the Hard disk backup time ● Hour: minute	
	32 Hard disk backup day	* Selects the Hard disk backup day ● Sunday, Monday, Tuesday, Wenes., Thursday, Friday, Saturday, Everyday	Sunday
	33 Backup to RMV media	* Selects the backup to removable media ● Stop, Start	Stop
	34 Restore from RMV media	* Selects the restore from removable media ● Stop, Start	Stop
8/8	35 Hard disk backup	* Selects the hard disk backup manually ● Stop, Start	Stop
	36 System version update	* Selects the system version update ● Stop, Start	Stop
	37 User ID input	* Selects the user ID input to use without ID card ● No, Yes	Yes
	38 User info. list print	* Allows printing user information (User name, Department name, Tel No. Code No., Password) ● Stop, Start	Stop
	39 (Reserved)		

NOTE

* Not needed in copying mode, but needed when installing options for advanced functions (see page 82) or using multi functions model (FP-D350H).

● It is necessary to input key operator ID code before changing items on this page.

User Preset

Copier Settings for Key Operator

■ **Input key operator ID code to change settings.**


User preset mode; copier select item
OK
00 Auto exposure default Manual
01 Original mode default T/P
02 Photo mode contrast Medium
03 T/P mode contrast Medium
04 Photo mode sharpness Medium
1/4
User preset mode; copier select item
OK
05 T/P mode sharpness Medium
06 Interleaving default Blank
07 Page insertion default Blank
08 Cover mode default F,Blank
09 SADF default No
2/4

Screen No.	Modes	Function	Initial setting
1/4	00 Auto exposure default	Determines whether to use Auto Exposure mode ● No, Auto, Manual	Manual
	01 Original mode default	Selects original setting ● Text, T/P (Text/Photo), Photo	T/P
	02 Photo mode contrast	Selects contrast for Photo mode ● Weak 2, Weak 1, Medium, Strong 1, Strong 2	Medium
	03 T/P mode contrast (Text/Photo mode)	Selects contrast for Text/Photo mode ● Weak, Medium, Strong	Medium
	04 Photo mode sharpness	Selects Sharpness for Photo mode ● Weak, Medium, Strong	Medium
2/4	05 T/P mode sharpness (Text/Photo mode)	Selects Sharpness for Text/Photo mode ● Weak, Medium, Strong	Medium
	06 Interleaving default	Selects OHP interleaving paper ● Blank, Copy	Blank
	07 Page insertion default	Selects Page Insertion ● Blank, Copy	Blank
	08 Cover mode default	Selects Cover paper ● F, Blank (Front cover blank), F, Copy (Front cover copied), FB, Blank (Front & back cover blank), FB, Copy (Front & back cover copied)	F, Blank
	09 SADF default	Enables or disables the use of SADF function. ● No, Yes	No

NOTE

● It is necessary to input key operator ID code before changing items on this page.

Copier Settings for Key Operator

■ Input key operator ID code to change settings.


User preset mode; copier select item
OK
10 Maximum copy setting OFF
11 Multisize rotation No
12 M1, size 70 x 160
13 M2, size 95 x 220
14 Text mode sharpness Medium
3/4



Screen No.	Modes	Function	Initial setting
3/4	10 Maximum copy setting	Determines whether to limit number of copies (1-99) or not	OFF (No limit)
	11 Multi-size rotation	When using the same size paper in Multi-size feeding mode, select the paper direction by rotating or not. ● No, Yes	No rotation
	12 M1, size	Input a size in memory 1 for frequent usage size. (X: width, Y: Length)	70 × 160 mm (X) (Y)
	13 M2, size	Input a size in memory 2 for frequent usage size. (X: width, Y: Length)	95 × 220 mm (X) (Y)
	14 Text mode sharpness	Selects sharpness for Text mode ● Weak, Medium, Strong	Medium
4/4	15 High speed duplex mode	Selects high speed duplex mode ● No, Yes	Yes
	16 Memory overflow warning	Selects the memory overflow warning ● Print, Cancel	Print
	17 Document save default	* Selects the document save default ● No, Yes	No
	18 (Reserved)		
	19 (Reserved)		

NOTE

* Not needed in copying mode, but needed when installing options for advanced functions (see page 82) or using multi functions model (FP-D250H/D350H).

● It is necessary to input key operator ID code before changing items on this page.

User Preset

User Setting

■ Paper size priority

Specifies the paper size in manual paper size setting mode.

1 **Press user preset key**



2 **Proceed according to screen order**



① Touch copier setting.


User preset mode; copier select item
OK
00 Margin value default 10mm
01 Edge value default 5mm
02 Book value default 20mm
03 Margin reduction def. 100%
04 Duplex mode default No
1/2

② Proceed to next page.


User preset mode; copier select item
OK
05 Reduce N in 1 for space No
06 Digital skyshot setting Freeshp
07 Manual skyshot setting OFF
08 Paper size priority A4
09 Set key operator code
2/2

③ Touch 08 (Paper size priority).

④ Touch paper size you require and touch OK key.

⑤ Press user preset key then exit user preset.

User setting for key operator

■ Check paper size

The paper trays are designed to accommodate A5, A4, A4R, B4·FLS and A3 size paper. To change the paper size, perform following steps as shown below.

1 **Press user preset key**

2 **Proceed according to screen order**

①Touch general functions



②Proceed to next page



③Select key operator key



④Input ID code (3 digit) and touch OK key



⑤Select 00 (Paper size)



⑥Touch paper drawer you require and select paper size*



Paper size is changing as follows.



⑦Touch **OK** key.

⑧Press user preset key then exit user preset

NOTE

* If the paper tray is not installed or is not inserted completely, the paper size indication will not appear.

3 Change paper guide inside of paper drawer and paper size indicator



①Pull out paper drawer and remove paper.



②Adjust paper guide ⓐ to the paper length.

③Adjust paper guide ⓑ to the paper width.

Squeeze the stopper to move the paper guide ⓑ to the desired paper size.



④Change the paper size indicator.

Take out and re-insert the indicator so the correct paper size is shown.
(A5 size is on the rear)

⑤Place new paper into drawer.

⑥Close paper drawer.

User Preset modes for Key operator.

■ Departmental counter

Key operator can manage, limit copies, counters and code numbers for each department.
(Maximum department number: 100)

1 **Press user preset key**

2 **Proceed according to screen order**

① Select General function



② Proceed to next page and select 09 key operator key.



③ Input ID code (3 digit) and touch OK key



④ Proceed to screen 3/8 and select 14 Departmental counter mode.



⑤ Select menu of total counter, count number, limited number or password, and touch OK key.



● Input 0 means total counters will be cleared.

NOTE

● To reset the user preset mode, press Reset key.

3 Change Number of Department counter, limit copy and code number.



Number of Department counter

① Select required department using the scroll key.
② Input "0" means clear all counts.
③ Touch **OK** key.

001 012346
- 012346: Counts (6 digit)
- 001: Department No. (3 digit)



Limit copy for each Department

① Select required department using the scroll key.
② Input limit copy number.
③ Touch **OK** key.

001 015000
- 015000: Limit copy number (6 digit)
- 001: Department No.



Code number for each department

① Select required department using the scroll key.
② Input code number.
③ Touch **OK** key.

001 112233
- 112233: Code number (1~6 digit)
- 001: Department No.

4 Exit user preset mode



① Touch **OK** key.
② Press user preset key on control panel.

NOTE

- To reset the user preset mode, press Reset key.

Options

Systems

2 Bin Finisher
(FA-F320)
- When hole punching copies.

(Lower bin functions)
- A4 size only. (Except A4 ☐)
- Single position stapling.
- Offset sets automatically.



3 Bin Finisher
(FA-F350/F355)
- Large capacity (Max. 1,550 copies)
- Multi-position stapling. (50 sheets)
- All 3 bins shift.

Options for 2/3 Bin Finisher
Exit Guide Unit
(FA-FK35)
- When 2/3 Bin Finisher is installed.

ADF, Automatic Document Feeder
(FA-A355)
i-ADF, Inverting Automatic Document Feeder
(FA-A888)
- To feed originals automatically.
- Multi-size feeding.
- For N in 1 copying.
- For duplex copying. (FA-A888 only)

Inverting Shift Tray
(FA-TR350)
2 Bin Inverting Shift Tray
(FA-TR355)
- Offset sets automatically
- 250 sheets capacity.

Inverting Unit
(FA-RU350)
- Face down.
- Used only with the 3 Bin Finisher.

Optional memory for Image operation*
- To enhance number of copies for electronic sorting.

ADU, Automatic Duplex Unit**
(FA-MADM65)
- For duplex copying. (50 sheets max.)

3000 Sheet Large Capacity Cassette
(FA-MA301)
- 3000 sheets

System Console
(FA-DS725/DS825)
- To increase paper feed sources and capacity. (Storage Drawer × 1)

Options for System Console
Paper Drawer
(FA-MA0555)
- 550 sheets

■ **Other Options**
Hard Disk for electronic sort
(FA-HD03)
Platen Cover
(FA-UC20)
Platen Cover Mounting Kit
(FA-GK35)
Exit Tray
(FA-X350)

NOTE

* Image Processing Memory for factory default setting is 8 MB (24 MB: FP-D350H). Please consult with Authorized Dealer for up-grading memory capacity.

**: On the FP-D350DC/D450/D600 type, the ADU (Automatic Duplex Unit/FA-MADM65) is standardly equipped.

Automatic Document Feeder

ADF (FA-A355)/i-ADF (FA-A888)

1. Features

①Automatic original feeding

- The ADF/i-ADF tray can hold up to 50 originals of 80 g/m² paper. (30 originals/B4·FLS, A3) It can accommodate originals from A5 to A3 size (50 to 110 g/m²).
- Automatic original size detection.

②Duplex Copying (FA-A888)

- The i-ADF allows you to perform two different types of duplexing automatically. (See P.15 – 20)

③Multi-size feeding

- Different size originals to be copied full size (1:1) or same size. (See P.51)

④2:1 Copy (FA-A888)

- Double sided original to single sided copies. (See P.16)

⑤N in 1 copy (FA-A888)

- To make a 1-sided copy (full size or reduction), from two (or four) 1-sided originals side-by-side. (See P.19)

⑥SADF (Single Automatic Document Feeder) Function

- A special original (like thin paper etc.,) can be fed from the ADF/i-ADF original tray and copied continuously with manual operation. (See P.21)

2. Components

FA-A355



FA-A888



3. Operation

■ Operation Procedure



Inappropriate originals

- Paper with a smooth surface such as glossy and coated papers
- Transparencies
- Originals with a lead edge that is creased, folded, punched or glued
- Paste-ups
- Pressure sensitive paper or paper with carbon backing
- Paper with excessive curl
- Stapled originals

(2) Combination of Multi-size feeding

Originals	Copies	
	Full Size	Reduction
A3 A4	A3 A4	A4R A4

3 Bin Finisher, Exit Guide Unit

FA-F350/F355/FK35

1. Features

FA-F350/F355 (3 Bin Finisher)



- Shift electronic sort copy
- Staple electronic sort copy
- Up to 50 originals (A4)/ 30 originals (A3, B4, A4 ☐)

FA-FK35 (Exit guide unit)

- Feeds paper to 3bin finisher

2. How to use







* The Shift-sort is not available in the first set, when the memory is full.

Select the type of copy group mode into inverting unit

① Non-sort
Copy is stored on the tray

② Shift-sort*
Multiple copies are sorted automatically and stacked with shift.

③ Staple-sort
Following functions can be selected by pressing staple-sort key.
③-1: Top left corner (1 position)
③-2: Left (2 positions) (except A4 ☐)
③-3: Bottom left corner (1 position)
③-4: Bottom left corner (1 position)

④ Shift-group
Multiple copies are stored by shifting

FA-F350/F355

3. Operation



(1) Bin Capacity (sheets)

Modes	Paper Size	Interrupt Tray	1 Bin	2 Bin	3 Bin
Staple-sort	A4	None	300 or (30 sets)	750	200 (20 sets)
	A4 R, B4·FLS, A3	None	150 or (30 sets)	500	100 (20 sets)
Non-sort Shift-sort Shift-group	A4, A5	50*	300	1000	200
	A4 R, B4·FLS, A3	30*	150	500	100

* Non-sort only

(2) Interrupt Copying

From the platen glass only.



3 Bin Finisher

FA-F350/F355

(3) When replacing the staple cartridge



The message shown on the left appears when the staples are out.

1



Open the stapler cover.

2



①Turn the lock knob in counter clockwise direction.

②Pull out the staple unit until it stops.

3



①Remove the empty staple cartridge.
NOTE: Leave any remaining staples in the stapler unit.

②Install the new cartridge.

③Push the staple unit back to original position, then turn the lock knob in clockwise direction.

4

Check the operation
Select the staple-sort mode with control panel and print the desired data.

NOTE

- If the unit fails to staple after replacing the staple cartridge follow the instructions below.
  ①Remove the staple cartridge.
  ②Pull down the stapler towards you.
  ③Press the release knob and swing the staple jam lever back and forth.

  If the unit still fails to work, contact your service provider.



2 Bin Finisher, Exit Guide Unit

FA-F320/FK35

1. Components

Upper Bin
- Stack face up
- Hole punch

Lower Bin
- A4 size only (Except A4 ☞)
- Stapling (Up to 30 originals)
- Shift electronic sort
- Stack face down



FA-F320

2. Features

■Upper Bin



● Sort by rotating sets



● Stack by punch

■Lower Bin



● Offset using electronic sorting



● Offset using punching and electronic sorting

● Sort by punching and stapling sets



● Sort by stapling sets

■FA-FK35 (Exit Guide Unit)
- Feeds paper to 2 bin finisher.
  FA-FK35 should be installed when installing FA-F320.

2 Bin Finisher, Exit Guide Unit

FA-F320/FK35

3. How to use







* In the punch mode, A3 size and A4 ▯ size are available. With other sizes, punch is not enough or lack of the hole(s).

Select the type of copy group mode into 2 bin finisher and press OK.

① Non-sort
Copy is stored on the tray.

② Sort
Multiple copies are sorted automatically and stacked with shift.

③ Sort-rotate (Upper bin only)
Copied sets are separated by rotation and exited onto tray.

④ Group-rotate (Upper bin only)
Grouped copies are rotated and exited onto tray.

⑤ Punch*
Sorted copies are punched and exited onto tray. (Except Sort-rotate and Group-rotate modes)

⑥ Shift-sort (Lower bin only)
Copied sets are offset and exited onto tray.

⑦ Shift-group (Lower bin only)
Grouped copies are offset and exited onto tray.

⑧ Staple-sort (Lower bin only)
Sorted copies are stapled and exited onto tray.

NOTE

- **When the image memory capacity of the copier is 8 MB;**
  Above sort modes may not be possible to use depending on the type of original such as gray originals and overflow indication will be appeared in the message display. In such a case, it is recommended either make copies by separate lots (except staple-sort) or install additional image memory (8 MB or 16 MB).

2 Bin Finisher

FA-F320

4. When replacing the staple



The message shown on the left appears when the staples are out.

1



Pull out the finisher.

2



Open the stapler cover.

3



①Lift up the lock lever.

②Raise up the stapler unit.

4



Remove the staple cartridge.

2 Bin Finisher

FA-F320

5



①Remove the empty staple case.

②Install the new staple case.

6



Pull out the tape.

7



Insert the staple cartridge.

8



Return the stapler unit to the original position.

9

①Close the stapler cover.

②Return the finisher to the original position.

10

Check the operation
Select the staple-sort mode with control panel and print the desired data.

FA-F320

5. If the unit fails to staple after replacing the staple follow the instruction below.

1

Remove the staple cartridge according to staple replacing procedures steps 1 to 4.
(See P.57)

2



①Open the staple cover.

②Remove the remained staple.

③Close the staple cover.

3

Reinstall the staple cartridge according to staple replacing procedures steps 7 to 10 and check operation. (See P.58)

6. Punch disposal (When replacing the staple)

1

Pull out the finisher.

2



①Pull out the trash box.

②Dispose the punch trash.

3



①Lift up the finisher entry guide.

②Return the trash box.

4

Return the finisher to original position.

Inverting Shift Tray

FA-TR350/TR355

1. Feature

Copies are stacked on the upper bin. (Lower bin is for printer function)



Offset using electronic sorting

Sort by rotating sets

2. Operation





1 Position original

2 Press Sort/Finish key

3 Select sort mode

4 Number of copies

5 Press **Print**



Select copy output method

① Non-sort*
Copies are exited onto tray.

② Shift-sort**
Copied sets are offset and exited onto tray.

③ Shift-group
Grouped copies are offset and exited onto tray.

④ Sort/rotate*
Copied sets are separated by rotation and exited onto tray.

⑤ Group/rotate*
Grouped copies are rotated and exited onto tray.

NOTE

* Non-sort, Sort/rotate and Group/rotate are available without the FA-TR350/TR355. Shift-sort and Shift-group require the FA-TR350/TR355.

** The Shift-sort is not available in the first set when the memory is full.

- The ADF/i-ADF is required for Sort/rotate and Group/rotate modes.
- Sort/rotate and Group/rotate functions are not available in the double sided copy, 2 page copy and 1 in N modes.

Adding Paper

550 Sheet Paper Tray

1



Pull paper tray out of copier.

Do not load ADU (option) with paper.

2



Place paper into paper tray.

Special papers, like glossy paper, mailing labels and transparencies cannot be used in the paper tray. Use bypass for special paper.

3



Make sure paper is not loaded above overfill indicator located in the paper tray.

Overfill Indicator



← Single sided copy

← Double Sided Copy*

4

Push paper tray back into copier.

ATTENTION

* When making double sided copies without an automatic duplex unit, place the copies face-up in the paper tray to the double sided overfill indicator.

- When the staple sorter is used:
  Some papers may not be suitable for stapling. Please check with your service department if you are unsure about the type of paper you are using.

Adding Paper

3000 Sheet Large Capacity Cassette (LCC)

1



①Open the door.
②The paper feed tray will go down.

Do not touch the tray while it is moving.

2



ADD PAPER

After tray stops, place paper neatly on to tray.
A4 size only (portrait).

3



Do not fill above red line.

Up to 3000 sheets, 80 g/m^2

4

Close the door.

Add Toner

When U13 appears

1



Open front panel.

Turn toner hopper assembly.

2



Remove toner bottle

①Turn empty toner bottle until it stops.

②Slide empty toner bottle towards you and remove.

3



Shake well before using.
10 – 15 times until the toner inside is evenly distributed.

Remove the cap from the bottle.

Do not turn the shutter.

4



①Insert new toner bottle to the hopper assembly.

②Turn the bottle until it stops, and arrows are aligned.



5

Return the toner hopper assembly to original position.
Close front panel.

ATTENTION

- For optimum copy quality use the recommended Panasonic toner. Store toner in a cool dark place. Do not unseal toner before use. Use it as fast as possible after unsealing.

Replacing the Waste Toner Bottle

When U14 appears

1



Open waste toner bottle cover.

2



Carefully remove the waste toner bottle by pulling it straight out as shown.

Do not squeeze the bottle.

3



Close bottle with cap.

4



Install new bottle.

Do not insert the bottle from the top.

5

Close waste toner bottle cover.

ATTENTION

- Do not use toner in waste toner bottle.

NOTE

- If you have no replacement waste toner bottle, please contact your service provider.

Removing a Paper Misfeed

■ **If a paper misfeed should occur, the misfeed indicator and misfeed position(s) will be shown on the touch panel display.**



Paper Misfeed Positions

	Copier or System Console	A: The paper exit area: (See P.66) B: Paper transport area (See P.67) C: Paper entry area (See P.67) LCC, Large Capacity Cassette (See P.68) D: Automatic Duplex Unit (ADU) (See P.70) E: System console (See P.68)
	ADF i-ADF	F: ADF/i-ADF (See P.69, 71)
	Finisher	G: FA-TR350/TR355 (See P.72 – 73) FA-F320 (See P.75) H: FA-F350/F355 (See P.74)

ATTENTION

- Make sure that the misfeed indicator goes off after removing a paper misfeed. The misfeed indicator will not go off if the paper is still remaining in the copier. Check again and remove all misfed paper.

Removing a Paper Misfeed

Paper exit area



1



①Open front panel.
②Open exit cover.

Note: If Finisher or Inverting shift tray is installed, move from the machine before above operation.

2



①Turn the left paper clearing knob.
②Remove misfed paper.

Left Paper Clearing Knob

3



Caution: this fuser area may be hot.

①Open the fuser guide.
②Check that no misfed paper is remaining.
③Close the fuser guide.

4

①Close exit cover.
②Close front panel.

ATTENTION

- The fusing area may be hot, so use caution when removing misfed paper.
- The front panel must be opened prior to opening the exit cover.
- Make sure that the misfeed indicator goes off after removing all misfed paper.
- After removing misfed paper, close front panel as soon as possible.

Paper transport and paper entry areas



1



Open front panel.

2



① Lower lever ⓐ.
② If copy paper is fed far into the copier, turn the right paper clearing knob.
③ Remove misfed paper.
④ Raise lever ⓐ to original position.

3



① Open the paper feed cover.
② Remove misfed paper.
③ Close entry cover.

4

Close front panel.

ATTENTION

- Do not touch or scratch the surface of the drum.
- Make sure that the misfeed indicator goes off after removing all misfed paper.

Removing a Paper Misfeed

System console/Large Capacity Cassette



1



System console

①Open the paper feed cover.
②Remove misfed paper.
③Close the paper feed cover.

2



Large Capacity Cassette

①Hold the latch and slide the large capacity cassette to the right.
②Remove misfed paper.



①Open the door.
②Remove misfed paper.
③Close the door.
④Return the large capacity cassette to original position.

ATTENTION

- Make sure that the misfeed indicator goes off after removing all misfed paper.

i-ADF



1



Entry Area

①Open entry cover.
②Remove misfed paper.
③Close entry cover.



①Open the i-ADF.
②Open entry cover.
③Remove misfed paper.
④Close entry cover and the i-ADF.

2



Exit Area

①Open the i-ADF.
②Remove misfed paper.
If paper is remaining on the platen glass, remove it.



If paper can not be removed:

③Close the i-ADF.
④Remove misfed paper.

ATTENTION

- Check that the paper misfeed indicator disappears. If not, raise and lower the i-ADF.

Removing a Paper Misfeed

Automatic Duplex Unit (ADU)



1



Pull out automatic duplex unit.

2



① Open paper guide plate.
② Remove misfed paper.
③ Close paper guide plate.

3



If misfeed is too far into the automatic duplex unit:

① Open paper transport section, until it stops.
② Remove misfed paper.
③ Close paper transport section.

4

Push back automatic duplex unit.

ATTENTION

- When the misfeed indicators light at A, C and D, remove misfed paper from A and C first then remove it in the ADU (D).
- Make sure that the misfeed indicator goes off after removing all misfed paper.

ADF



1



Paper feed unit

①Close exit tray.



②Open the paper feed cover.
③Remove misfed paper.
④Close the paper feed cover.
⑤Put exit tray back.

2



Paper exit

①Open the paper feed cover.
②Remove misfed paper.



②Open exit cover.
③Make sure no paper remains.
④Close exit cover.

ATTENTION

- Check that the paper misfeed indicator disappears. If not, raise and lower the ADF.

Removing a Paper Misfeed

Inverting Shift Tray (FA-TR350)



1



① Hold release lever.
② Open inverting shift tray until it stops.

2



① Open transfer guide.
② Remove misfed paper.
③ Close transfer guide.

3



Close inverse shift tray.

ATTENTION

- Make sure that the misfeed indicator goes off after removing all misfed paper.

2 Bin Inverting Shift Tray (FA-TR355)



1



①Hold release lever.

②Open the 2 bin inverting shift tray to the left until it stops.

Pull out gently.

2



①Open transfer guide.

②Remove misfed paper.

③Close transfer guide.

3



Return the 2 bin inverting shift tray to the original position.

ATTENTION

- Make sure that the misfeed indicator goes off after removing all misfed paper.

Removing a Paper Misfeed

3 Bin Finisher (FA-F350/F355)



1



Press the lock release button and open the finisher to the left.

Pull out gently.

2



Open the interrupt tray

3



① Open the top cover.

② Open the buffer roller cover.

③ Remove misfed paper.

④ Close the buffer roller cover and top cover.

4

Return the finisher to the original position.

ATTENTION

- Make sure that the misfeed indicator goes off after removing all misfed paper.

2 Bin Finisher (FA-F320)



- Make sure that the misfeed indicator goes off after removing all misfed paper.

1



①Lift up the upper cover.

②Remove misfed paper.

2



①Pull out the finisher.

②Pull out the trash box.
(See P.59)

③Open the stapler cover.
(See P.57)

3



①Turn the paper transport knob A.

②Remove misfed paper.



When paper cannot be removed:

Lift up the finisher guide and remove misfed paper.



When the misfed paper is not found:

①Turn the paper transport knob B.

②Remove misfed paper.

4

①Close the staple cover and install the trash box.

②Return the finisher to original position.

Troubleshooting

Before you call service

Check	Action
Unit does not operate	
Does the display light? (See P.9)	Check if the Power Switch is turned on and if the power plug is inserted into the outlet.
Does the Energy saver key flash (or light) and displays are turned OFF? (See P.33)	Press Energy saver key on control panel.
Do any of the U## codes and messages appear on display? (U0, U4, U10, U12, U14....etc.,)	Perform actions in accordance with each message.
Does the add staples indicator and message appear on display? (⊂⊃) (See P.54)	Add staples. (See P.54)
Does the add paper indicator and message appear on display? (🖹) (See P.11)	Add paper. (See P.61, 62)
Does paper misfeed indicator and message appear on display? (8⋀) (See P.65)	Remove misfed paper. (See P.66 – 75)
Does any of the E#-## indicator and message appear on display?	Turn copier power switch off, then back on. If error code comes back again, call service.

Before you call service

Check	Action
Copies are light	
Does the exposure indicator say "light"?	Touch the "dark" key or touch the "Auto" key to choose the auto mode. (See P.12)
Does the add toner indicator and message appear on displays?	Add toner. (See P.63)
Copies are marked	
Is the copier platen glass or platen cover dirty?	Clean the glass or platen cover. (See below)

■ If the measures outlined above do not solve the problem, call for Service.

■ Cleaning

As a rule, clean once a week.



Platen/Platen Cover
① Gently wipe marks off with cloth and neutral detergent.
② Gently wipe again with a dry cloth.

Specifications

■ FP-D250/D350/D350DC/D350H/D450/D600

Type:	Desk Top
Copy/Print Process:	Laser/Electrostatic photographic method
Process:	Dry, New Mgnefine High Definition Toner
Resolution: (Copy mode)	Max. 600 dpi (FP-D250/D350/D350DC/D350H) Max. 400 dpi (FP-D450/D600)
Resolution: (Print mode)	Max. 600 × 600 dpi Max. 1,200 × 600 dpi (with smoothing)
Image Memory:	8 MB (24 MB: FP-D350H) (for Electronic Sort/Group)
Multi-Copy Speed:	28 A4 size copies per minute (FP-D250) 35 A4 size copies per minute (FP-D350/D350DC/D350H) 45 A4 size copies per minute (FP-D450) 60 A4 size copies per minute (FP-D600)
Maximum Copy Size:	A3 (297 × 420 mm) Void Area: max. 5.0 mm
Copy Size:	A3 - A5 via paper drawer/tray A6R - A3 via sheet bypass
Reduction Ratios:	Preset: 87%, 82%, 71%, 58%, 50% Variable: from 99% to 25% in 1% increments
Enlargement Ratios:	Preset: 115%, 122%, 141%, 173%, 200% Variable: from 101% to 400% in 1% increments
Paper Feed:	550 sheet paper drawer × 2 (× 1: FP-D450/D600) plus 50 sheet Bypass Automatic Switching
Paper Selection:	Automatic
Paper Weight:	Paper drawer/tray: 60 – 90 g/m^2 Bypass: 55 – 130 g/m^2
Quantity Selector:	1 – 999, Automatic Repeat, Automatic Reset to 1
Exposure Control:	Automatic, Text/Photo, Text and Photo Mode
Toner Supply:	Automatic
Dimensions:	606 (W) × 770 (D) × 624 (H) mm
Weight:	76 kg (FP-D250/D350) 80 kg (FP-D350DC) 82 kg (FP-D350H) 84 kg (FP-D450/D600)
Electrical Requirements:	AC 220-240V, 50Hz, 6.5A

Specifications are subject to change without notice.

■ i-ADF (FA-A888), ADF (FA-A355)

Original Capacity:	30 sheets/B4·FLS, A3 50 sheets/A5, A4
Paper Size:	A5, A4, A4 R, B4·FLS, A3
Paper Weight:	50 – 110 g/m^2
Electrical Requirements:	Supplied from copier
Dimensions:	622 (W) × 546 (D) × 117 (H) mm without Tray (FA-A355) 600 (W) × 519 (D) × 120 (H) mm without Tray (FA-A888)
Weight:	11 kg (FA-A355) 12 kg (FA-A888)

■ Inverting Shift Tray (FA-TR350)

Paper Size:	A5, A4, A4 R, B4·FLS, A3
Paper Weight:	60 – 90 g/m^2
Bin Capacity:	Non-sort, Sort/rotate, Group/rotate: 250 sheets Shift-sort, Shift-group : 200 sheets (A4, A5) 150 sheets (A3, B4·FLS)
Electrical Requirements:	Supplied from copier
Dimensions:	79 (W) × 582 (D) × 419 (H) mm
Weight:	9 kg

■ 2 Bin Inverting Shift Tray (FA-TR355)

Paper Size:	A5, A4, B4·FLS, A3
Paper Weight:	60 – 130 g/m^2 (Face Down: 60 – 90 g/m^2)
Number of Bins:	2
Bin Capacity:	
Upper	Non-sort, Sort/rotate, Group/rotate: 300 sheets (A4, A5) 200 sheets (A3, B4·FLS) Shift-sort, Shift-group : 200 sheets (A4, A5) 150 sheets (A3, B4·FLS)
Lower	300 sheets (For printer function only)
Electrical Requirements:	Supplied from copier
Dimensions:	259 (W) × 582 (D) × 522 (H) mm
Weight:	16.2 kg

Specifications are subject to change without notice.

Specifications

■ 3 Bin Finisher (FA-F350/F355)

Paper Size:	A5, A4, A4 R, B4 FLS, A3	
Paper Weight:	50 – 128 g/m²	
Number of Bins:	3 + Interrupt Tray	
Bin Capacity:		
Interrupt Tray	50 sheets	
1 Bin	300 sheets	
2 Bin	1,000 sheets	(See page 53 for detailed information)
3 Bin	200 sheets	
Electrical Requirements:	Supplied from copier	
Dimensions:	669 (W) × 582 (D) × 1,039 (H) mm (FA-F350) 669 (W) × 603 (D) × 1,039 (H) mm (FA-F355)	
Weight:	34.5 kg (FA-F350) 36.0 kg (FA-F355)	

■ 2 Bin Finisher (FA-F320)

Paper Size:	Upper Bin: A5, A4, B4 FLS, A3 Lower Bin: A4
Paper Weight:	60 – 105 g/m² (Upper Bin, without punch: 60 – 130 g/m²)
Number of Bins:	2
Bin Capacity:	
Upper	100 sheets
Lower	1,000 sheets (When sorting mode: maximum 30 sets and/or 1,000 sheets)
Electrical Requirements:	Supplied from copier
Dimensions:	405 (W) × 520 (D) × 438 (H) mm
Weight:	16.2 kg

Specifications are subject to change without notice.

■ System Console (FA-DS725/DS825)

	FA-DS725	FA-DS825
Combination:	Storage Drawer × 1	550 Sheet Paper Drawer × 1 Storage Drawer × 1
Paper Size:	A5, A4, A4 R, B4·FLS, A3	A5, A4, A4 R, B4·FLS, A3
Paper Weight:	60 – 90 g/m²	60 – 90 g/m²
Electrical Requirements:	Supplied from copier	Supplied from copier
Dimensions:	606 (W) × 661 (D) × 416 (H) mm	606 (W) × 661 (D) × 416 (H) mm
Weight:	22 kg	27 kg
Applicable models:	FP-D250/D350/D350DC/D350H	FP-D450/D600

■ Large Capacity Cassette (FA-MA301)/Automatic Document Unit (FA-MADM65)

	FA-MA301	FA-MADM65
Paper Size:	A4	A5R – A3
Paper Weight:	60 – 90 g/m²	60 – 90 g/m²
Paper Capacity:	Maximum 3000 sheets, 80 g/m²	Maximum 50 sheets, 80 g/m²
Electrical Requirements:	Supplied from system console	Supplied from copier
Dimensions:	290 (W) × 445 (D) × 517 (H) mm	——
Weight:	15 kg	9 kg

Specifications are subject to change without notice.

System Information

■ The FP-D250/D350/D450/D600 series are powerful multi-function digital copiers which can combine copying, printing, electronic filing and network functions all in one unit! Superior output quality is ensured with 600 dpi resolution in both copying and printing modes.
(Note: 400 dpi for FP-D450/D600 in copying mode.)
We hope you find that the wide ranging capabilities of the FP-D250/D350/D350DC/D450/D600 will make your office-place more productive and efficient.

■ Procedure for system upgrades



FP-D250
FP-D350
FP-D350DC
FP-D450
FP-D600



● Before system upgrades

Part name	Part No.	Remarks
Printer Controller/ HDD Mounting Kit	FA-PK30	Control panel for mounting the printer and filing

For Filing

Part name	Part No.	Remarks
1. DD Filing Unit (For FP-D250/D350/D350DC)	FA-WA01	Set up unit for Filing • Hard Disc (2GB) • Card reader • Removable media • Battery • Personal cards (10)
2. DD Filing Unit (For FP-D450/D600)	FA-WA02	
3. DD Browser Software	FA-WB10	For FA-WA01
4. Hard Disk Drive for Backup	FA-HD02	For FA-WA01

For Printer

1. Printer Unit	FA-PC350	Printer controller for PCL5e*
2. Multi Page Description Language Controller	FA-MC350	Printer controller for PS printer and PCL5e
3. Hard Disk Drive for Printer	FA-HD01	For FA-PC350 or FA-MC350

For Network

Network Adapter Unit	FA-NE35	Network PCB (Ethernet) for printer and filing

NOTE

* PCL5e is the Page Description Language of the H.P. Company.

● Information regarding the options for Filing, Printer, Network can be found in each of the options respective operating guides.

For Service Call: _____

Matsushita Electric Industrial Co., Ltd.
Osaka 542-8588, Japan

FFPTD0921 S0699-0
June 1999
Printed in Japan

English